- 1. WALL/KILN SPACING: 12" [30.5cm] SPACING BETWEEN SIDES OF KILN AND WALLS 4. OR OTHER OBJECTS. 18" [45.7cm] IS RECOMMENDED. LEAVE AT LEAST 18" [45.7cm] BETWEEN TWO KILNS.
- 2. AMBIENT VENTILATION: SEE CHART TO RIGHT FOR RATINGS. TO CALCULATE REQUIREMENTS, SEE hotkilns.com/calculate-kiln-room-ventilation.

MADE FROM

5

NEW

3. KILN VENTILATION: L&L VENT-SURE KILN VENT RECOMMENDED FOR SAFETY AND LONGER ELEMENT LIFE. OPTIONAL CONTROL ALLOWS VENT TO BE TURNED ON AND OFF WITH CONTROL.

Λ

BTUS/ KILOJOULES PER HOUR NEEDED TO BE VENTED WITH AMBIENT ROOM VENTILATION (THIS IS IN ADDITION TO KILN VENTING): AT TEMP F BTUS AT TEMP C **KILOJOULES** 1800F 21651 980C 22843 2000F 25311 1095C 26704 15.6in 31531 2232F 29886 1222C [39.6cm] 2350F 32346 1285C 34127 12.0in 30.5cm 12.7in THIS MODEL IS [32.2cm] DIRECT WIRED. THERE IS NO POWER CORD. 2.5in 78.8in [200.1cm] 6.4cm LEAVE AT LEAST 30" FREE SPACE FROM A KILN LEAVE 24" FREE SURFACE FOR 21" [53.3cm] SPACE IN FRONT USER TO LOAD KILN **KILN FURNITURE** OF CONTROLLER FOR OPERATION (OPTIONAL) AND MAINTENANCE 54.0in [137.1cm] 505 SHARPTOWN RD REV SHEET OF DRAWING NO. DRAWN BY DATE SCALE TITLE 02/01/20 1:15 1/3 DSL 235-000-45-5 0 JD245V (2.5" BRICK) GENERAL DIMENSIONS PH: (856) 294-0077

3

- **OTHER INFO:** REFER TO INSTALLATION INSTRUCTIONS AND CAUTIONS INSTRUCTIONS FOR OTHER REQUIREMENTS AND SAFETY INFORMATION. REFER TO WIRING DIAGRAM FOR ELECTRICAL HOOKUP INFORMATION.
- MAX LOAD WEIGHT: SEE hotkilns.com/load-weight. 5.
- WEIGHT OF KILN: 415 LBS, 188 KG 6.

2



