



| Wiring Information | |
|---|-------------------------|
| Power | 10AWG / 150°C / 600V |
| Control | 16-22AWG / 105°C / 600V |
| Power Supply Wire Gauge assumes 75°C Copper Wire. See hotkilns.com/wire-size. | |

| Model: e23M-208-3P | |
|--|----------------------------|
| Voltage | 208 / 3 / 50-60 |
| Watts | 11,520 |
| Full Load Amps | L1 L2 L3 38.4 29.3 29.3 |
| Power Supply | Fuse Wire 50A 8AWG |
| Standard Elements: E-E-23ML/22 Quad Elements: E-E-23MQ/22 | |
| Quantity: 5 | Ohms: 18.1 |

| Model: e23M-240-3P | |
|--|----------------------------|
| Voltage | 240 / 3 / 50-60 |
| Watts | 11,520 |
| Full Load Amps | L1 L2 L3 33.3 25.4 25.4 |
| Power Supply | Fuse Wire 50A 8AWG |
| Standard Elements: E-E-23ML/31 Quad Elements: E-E-23MQ/31 | |
| Quantity: 5 | Ohms: 24.1 |

Industrial & commercial applications may require the installation of a LOCKOUT/TAGOUT device to prevent the kiln from operating during maintenance.

This kiln is recommended to be wired & connected to an approved U. L. & NEC configured receptacle controlled with a disconnect switch and properly fused according to the kW load specification listed on the kiln nameplate. L&L Kiln Mfg., Inc., also recommends fuses rather than circuit breakers to prevent nuisance tripping.

| E23M Easy-Fire 3 Phase 208V, 240V (C0018) | | | | |
|---|------------|-------------|--------------|----------------|
| | | | | |
| A | 05/11/2026 | AF | Drawn by: AF | |
| Rev. | Date | Description | Approved by | Dwg. No. C0018 |